

Long-Term Thermo-Oxidative Degradation of High-Temperature Polymers and their Composites

Kishore Pochiraju

***Dept. Mechanical Engineering,
Stevens Institute of Technology, Hoboken, NJ 07030***

Collaborators

G. Tandon & Endel larve (UDRI)

Greg Schoeppner & Richard Hall (AFRL)


Doctoral Students

Nan An (2013), Jianyong Liang(2014), Padmalatha Kakanuru(2016)



Workshop #3: Exploring the Pivotal Role of Next Generation X-rays in Bridging the Scale-Gaps in Next Generation Energy Materials under Extremes
2014 NSLS/NSLS-II & CFN Joint Users' Meeting
May 19th, 2014

High Temperature Composites & Aging




Age-Related Degradation

1. **Physical aging**, including the creep and relaxation of the matrix and fiber-matrix interphase;
2. **Chemical aging**, controlled by the thermo-oxidative degradation of the matrix and fiber-matrix interphase;
3. **Micromechanical** damage growth and failure



Oxidation of Polymers and Composites

Avimid-N/IM6 (650°F/343°C)

Wang, Chen, Skontorp, 2003




Weight Loss?



Tandon et al. 2011


TOS is orthotropic and heterogeneous in Lamina
Weight loss of constituents cannot be used for composite design

Goal: A Scalable Methodology




Isothermal Aging Studies

Oxidation Layer Size and Growth



Isothermal Aging



Optical Microscopy



Bright-Field



Dark-field




Fluorescence



Differential Interference Contrast





- Previously used techniques (*bright-field*, *dark-field*, *fluorescence imaging*) unable to track oxidation growth in neat resin
- A new technique based on differences in index of refraction of oxidized and unoxidized regions is successful

Oxidation Layer Characterization: Nano-indentation




- Oxidation transition zone between oxidized edge zone and specimen interior remains relatively constant for all aging times.
- Significant increases in resin stiffness in oxidation layer.

Energy Dispersive Spectroscopy



- Chemical depth profiling using the Genesis elemental analysis software
- Relative oxygen content is higher in the oxidized region
- Distribution provides estimation of the extent of the oxidized region


Comparison of Mechanical, Optical and Chemical Mapping



Different techniques validate extent of oxidized region

Oxidation Layer Characterization: CT Scanning

PMR-15 aged for 3112 hrs



- CT scans show the damage and oxidation layer sides in the specimen
- Oxidation layer thickness can be correlated to those obtained from other techniques
- Crack length and density can be determined throughout the entire specimen


Validation of Optical Microscopy Technique for Damage Assessment

3000 hr
@ 450°F



Fluorescence imaging of cracks


A wide-field fluorescence image of a material cross-section. The image is predominantly dark, with numerous bright, irregular, and elongated spots and lines distributed throughout, representing the locations of cracks that have fluoresced under the imaging conditions.



Edge

A high-magnification X-ray image of the edge of a material cross-section. It shows a detailed view of the internal structure, with dark, elongated, and somewhat parallel features that represent cracks or voids within the material.

X-ray imaging of cracks



Center


A high-magnification X-ray image of the center of a material cross-section. Similar to the edge view, it shows a detailed view of the internal structure with dark, elongated features representing cracks or voids, providing a comparison of damage distribution between the edge and the center.

- Polished discrete section is representative of the damage behavior in the interior
- Similar damage growth and distribution observed


Mechanisms of Oxidative Degradation

Oxidation


Oxidative Degradation




- Phase I: Exposure and boundary sorption
- Phase II: Heterogeneity in diffusivity induces anisotropic oxidation
- Phase III: Conversion into oxide products induces oxidation-driven strain and damage evolution
- Phase IV: Newly formed surfaces promotes diffusion



Coupled Oxidation-Damage Mechanisms



Oxidation Model



Modeling Thermo-Oxidation of Polymers

Diffusion-Reaction System

$$\begin{aligned}\frac{dC(x,t)}{dt} &= D(\phi, T) \frac{d^2 C(x,t)}{dx^2} - R(C, T, \phi) \\ C(0,t) &= C^s \text{ mol/m}^3 \\ \frac{dC}{dx}(L,t) &= 0.0 \\ C(x,0) &\sim 0 \text{ mol/m}^3\end{aligned}$$

Reaction Rate Model

$$\begin{aligned}R(C, T, \phi) &= R_0(T) \psi(C) \left\{ \frac{\phi - \phi_{ox}}{1 - \phi_{ox}} \right\} \\ &= R_0(T) \frac{2\beta C}{1 + \beta C} \left(1 - \frac{\beta C}{2(1 + \beta C)} \right) \left\{ \frac{\phi - \phi_{ox}}{1 - \phi_{ox}} \right\} \\ R_0(T) &= R^* e^{\frac{-R_a}{RT}}\end{aligned}$$

Conversion Model


$$\begin{aligned}\frac{d\phi}{dt} &= \alpha(t) R(C) \\ 1 &< \phi < \phi_{ox} \\ \alpha(t) &= \alpha^* \text{ (constant)} \\ &= \begin{cases} \alpha^1 + \alpha^2 \left(\frac{t^* - t}{t^*} \right) : t < t^* \\ \alpha^* : t > t^* \end{cases}\end{aligned}$$

Oxidation State Dependent Diffusivity

Phase(ϕ) and Temperature (T) Dependent

$$\begin{aligned}D_{ij}(\phi, T) &= D^{un}(T) \left(\frac{\phi - \phi_{ox}}{1 - \phi_{ox}} \right) + D^{ox}(T) \left(\frac{1 - \phi}{1 - \phi_{ox}} \right) \\ D^{un}(T) &= D_{un}^* e^{\frac{-E_a^{un}}{RT}} \\ D^{ox}(T) &= D_{ox}^* e^{\frac{-E_a^{ox}}{RT}}\end{aligned}$$

Oxidative Layer Growth in PMR-15




Stress-Coupled Diffusion-Reaction Modeling

RATE OF CHANGE OF
O₂ CONCENTRATION

Stress-coupled Diffusivity and

REACTION OR
CONSUMPTION TERM


$$\frac{\partial C(x, t)}{\partial t} = [D(\phi, T) + Ne] \nabla^2 C(x, t) - (M - N) \nabla e \cdot \nabla C(x, t) - R^*(C(x, t), \phi)$$


Boundary Sorption = Solubility \times Partial Pressure O₂ $\rightarrow C_S = SP_{O_2}$

Periodic/Symmetric Boundary conditions $\rightarrow \nabla C \cdot n = 0$



Diffusivity Assumed to obey Arrhenius Law $\rightarrow D_{ij} = D_{ij}^0 \exp\left(-\frac{E_a}{RT}\right)$

Oxidation in the Vicinity of Cracks


Oxidation growth at the crack tip in BMI resins



Angular variation of stress correlates to the oxidation depth around cracks




Oxidation of Unidirectional Lamina





Unidirectional G30-500/PMR-15
aged at 288°C

- Oxidized resin becomes lighter in color
- Development and growth of voids and microcracks into surface
- **Preferential oxidation in axial direction**



Fiber Orientation Dependent Oxidation




**Both Oxidation
Growth and damage
propagation are
Orthotropic**

**Penetrates deeper
into the laminate
along fiber direction**

Heterogeneous Laminate Behavior

Cross-ply laminate, $[0/90]_{4s}$


View is of cross-section perpendicular to 0° direction




- Preferential oxidation growth along the fiber paths for the cross-ply laminate
- Maximum/minimum oxidation extent occur at the plies midplane

Oxidation of Laminates

750 hr



$[0]_{16t}$



$[0/45/-45/90]_{2s}$





$[0/90]_{4s}$

- Short fiber matrix debonds along the 0° fiber direction
- Oxidation has advanced to a greater extent in the region of the specimen corresponding to the location of the debond cracks


Parallel to 0 degree direction

Modeling Oxidation of Laminates (No Damage)







- Anisotropy can be effectively modeled **in areas without damage**
- Requires 3D simulations and orthotropic diffusivity tensor
- Most effects are confined to adjacent plies

Optical and Fluoroscopic Imaging



Aged at 288 °C 405 Hours


Thermal-Oxidation in Laminates



$[0/90]_{4S}$

$[0/\pm 45/90]_{2S}$


Coupled Oxidation-Damage Scheme



Oxidation induces Shrinkage Strains


Micromechanical effects due to morphological changes

Modulus Changes




$$E(\phi, T) = E_{un}(T) e^{\left(K_{ox} \frac{1-\phi}{1-\phi_{ox}} \right)} e^{\left(K_{nox} \frac{\phi - \phi_{ox}}{1-\phi_{ox}} t \right)}$$

Resin Shrinkage




$$\beta(\phi, t, T) = \beta_{\phi}(T) \frac{\phi - \phi_{ox}}{1 - \phi_{ox}} + \beta_t(T) t_a$$

Evolution of Stress During Oxidative Aging




- Oxidation Layer (Left) and stress fields (right) after 10 Hours of aging.
- The peak Von Mises effective stresses (2.4 MPa) are at the fiber matrix interface and free edge (below)
- Average interstitial matrix stresses are at 0.4 MPa and in fiber is 2.4 MPa

- Oxidation Layer (left) shown at 200 hours
- Peak stress on the free edge is 47.3 MPa
- Average interstitial matrix stresses are at 1.2 MPa
- Average fiber stress = 25 MPa
- Matrix strength ~ 41MPa @288 C




Coupled Oxidation & Damage Model




Oxidation and Damage States in a Lamina

Along the fiber (axial)



Time = 900 Hrs


Transverse to fiber (axial)




Time = 1700 Hrs

Low Toughness – Faster Crack/oxidation growth

Axial Oxidation and Damage Growth




Oxidation and damage evolution simulation for a G30/PMR-15 lamina in the axial (fiber) direction







Axial Oxidation and Damage Growth



Transverse Oxidation and Damage Growth




***Oxidation and damage evolution simulation
for a G30/PMR-15 lamina in the transverse direction***






Transverse Oxidation and Damage Growth



Coating Morphology & Materials





Bismaleimide with Ag Coating with Cr interlayer < 10 nm

Average oxidation thickness on coated surface = $78.11 \pm 1.4 \mu\text{m}$

198 hrs


Average coating thickness $1.76 \pm 0.26 \mu\text{m}$

Average oxidation thickness on uncoated surfaces = $89.32 \pm 7.64 \mu\text{m}$




Oxidation Layer Characterization

Chemical Depth Profiling with EDAX




- Ratio of Oxygen to Carbon is monitored through the depth
- Fully oxidized regions have considerably higher ratio
- Oxidation layer size can be quantitatively measured.

Performance of Various Coating Materials




- Effectiveness correlates to the durability of the interface.
- Surface roughness did not provide additional mechanical bond strength or durability
- Between reactive metals - Cr bond layer is relatively more effective than Al.

Surface Damage Observations in T650-35/MVK-14 8HSW Textile Composites




1250 hr

Lab Air, 15 Psi



Argon



Lab Air, 75 psi

Little damage in argon, while increase in surface crack density under elevated pressure

Concluding Remarks

- Coupling effects for *Oxidation-on-Damage evolution* (though material response changes) and *Damage-on-Oxidation* (creation of new surfaces) have been captured.
- What's next?
 - Life prediction requires “careful” acceleration of “degradation”
 - Reduce scale of the specimens?
 - Not much room for temperature acceleration, pressure acceleration?
 - Analyze, characterize and control slow chemical degradation process?
 - New and novel structure visualization techniques, preferably non-destructive

Questions?

or e-mail: *Kishore.pochiraju@stevens.edu*